


SC-09 cable user manual

(english)



Art.Nr. 9359.M

11.02.2021

© PI 2021

index of contents

SC-09 cable

1 Description

2 Technical data

2.1 Pin assignment RS232

2.2 Pin assignment RS422

SC-09 cable

1 Description

(CONVERTER RS232-RS422/485)

The SC-09 connects a PC to the programming interface of a Mitsubishi PLC (Fx - and A - series) via the serial interface (COM 9 pole).

With the included adapter it is possible to couple to controllers that have a 25-pin Sub-D respectively an 8-pin Mini-DIN programming port.

2 Technical data

2.1 Pin assignment RS232

Pin number	Short form	Designation	Direction
1	NC	not used	
2	TXD	transmit data	output
3	RXD	receive data	input
4	NC	not used	
5	GND	signal mass	
6	NC	not used	
7	CTS	clear to send	output
8	RTS	request to send	input
9	NC	not used	

2.2 Pin assignment RS422

Pin number	Short form	Designation	Direction
1	NC	not used	
2	TXD +	transmit data +	output
3	RXD +	receive data +	input
4	RTS +	request to send +	output
5	CTS +	clear to send +	input
6	NC	nicht belegt	
7	GND	signal mass	input
8	GND	signal mass	Eingang
9	NC	not used	
10	NC	not used	
11	NC	not used	
12	VCCin	input Voltage (+5V DC)	input
13	VCCin	input Voltage (+5V DC)	input
14	NC	not used	
15	TXD -	transmit data -	output
16	RXD -	receive data -	input
17	RTS -	turn on transmitting part -	output
18	CTS -	ready to send -	input
19	NC	not used	
20	connect	connection to Pin 21	
21	connect	connection to Pin 20	
22	NC	not used	
23	NC	not used	
24	VCCin	input voltage (+5V DC)	input
25	VCCin	input voltage (+5V DC)	input