

## Handling-Shortinstruction for

### AC adapter




#### Important instructions:

Please read user instructions before use. Always observe these instructions.

This unit should be only operated at an ambient temperature between 0°C to 45°C up to 95% relative humidity, no condensation.

#### Mounting the primary plug

The primary plug is interchangeable. This allows a worldwide use. The procedure of changing the plugs is as per the pictures.



#### Pinning:

Red wire end ferrule: +24V DC  
Black wire end ferrule: 0V (Ground)

Under the web-address <https://www.process-informatik.de> are product specific documentations or software-driver/-tools available to download.  
If you have questions or suggestions about the product, please don't hesitate to contact us.

Process-Informatik Entwicklungsgesellschaft mbH

Im Gewerbegebiet 1

DE-73116 Wäschenbeuren

+49 (0) 7172-92666-0

[info@process-informatik.de](mailto:info@process-informatik.de)

<https://www.process-informatik.de>

Copyright by PI - 2025

**Menutree Website:**


- + Products / docu / downloads
- + Accessories
  - + Connector / Power supply
  - + AC adapter

**QR-Code Website:**



Please make sure to update your drivers before using our products.

## LOGO! - not just a small controller



For many PLC programmers and PLC users, the LOGO! is a "toy", but that's not the case.

The LOGO! is a small-control that also finds its use. With the tools and hardware devices around the LOGO!-PLC, the user can process information in and from the LOGO! PLC.

Regardless of whether current-/voltage-values are stored in the LOGO! is to be processed, the LOGO! sent E-mail-messages, here the user will find many products related to LOGO!.

## S5-PLC over USB




Communication with S5-PLC via USB, just how and with what?

Data-communication with S5-PLC from PC or other devices via USB, which interface is required. Questions you don't have to worry about. With "S5 over USB" you get the right interface-products for your interface of the PLC.

Which one you use then is up to you.

Separate your machine-net from the office-net



You need a separation between the machine-net and the office-net? No problem, plug a PCMCIA-LAN-card in your Tele-Prof-II-device (only for version -H) and the separation is OK. You have access to both nets via remote maintenance.

Management of the IP address

IP-Zugriffsschutz

Schutzmodus:

IP-Adresse / IP-Bereich #1:

IP-Adresse / IP-Bereich #2:

IP-Adresse / IP-Bereich #3:

IP-Adresse / IP-Bereich #4:

IP-Adresse / IP-Bereich #5:

IP-Adresse / IP-Bereich #6:

IP-Adresse / IP-Bereich #7:

IP-Adresse / IP-Bereich #8:

IP-Adresse / IP-Bereich #9:

IP-Adresse / IP-Bereich #10:

IP-Adresse / IP-Bereich #11:

IP-Adresse / IP-Bereich #12:

IP-Adresse / IP-Bereich #13:

IP-Adresse / IP-Bereich #14:

IP-Adresse / IP-Bereich #15:

IPs aus Liste verbieten

192.168.178.10	- Bereich (optional)
192.168.178.100	- 192.168.178.200
192.168.178.254	- Bereich (optional)
	- Bereich (optional)
	- Bereich (optional)
	- Bereich (optional)
	- Bereich (optional)
	- Bereich (optional)
	- Bereich (optional)
	- Bereich (optional)
	- Bereich (optional)
	- Bereich (optional)
	- Bereich (optional)
	- Bereich (optional)
	- Bereich (optional)
	- Bereich (optional)

The IP filter is used to determine whether or not the entered IP-addresses or IP-address-ranges may communicate with the connected controllers via the module.

The list can be edited centrally be switched with a button from "allowed" on "not allowed".