# handling-short instruction for

## **Mini-Prommer-III V1.1**

## Interface-Overview:



### **Connectors:**

#### RS232:

Connection to the Personal Computer or Notebook is made by the supplied 1 : 1 serial screened cable (2m long). This cable goes into the 9pin female connector of the MINI-PROMMER-III. The 9pin male connector is a replica of the 9pin male plug of the PC com port. It operates at up to 19200 Bd if the MINI-PROMMER-III is idle (green LED flashes). You can connect a mouse or a PLC here. The pinout is that of a 9pin male serial com port of the PC.

#### **Power Supply:**

The MINI-PROMMER of 22V - 33 Volts (27,5V+/-20%) DC. Current consumption is about 300 mA (8VA). Connection is made by a zwo pole screw type plug.



### Light emitting diode:

LED	State	Declaration
green	OFF	Incorrect power supply or wrong polarity
green	flashing	Idle state. The serial port of the PC is looped through. The Adapter watches the data lines of the PC and waits for the start sequence.
green	ON	The MINI-PROMMER III has been activated, the loop has been disconnected.
yellow	ON	The unit has received an instruction from the connected PC.
red	ON/OFF	This LED is used for error messages.

#### Software-installation:

Please download from the product-page of your device the WinPromm-software and install it on your PC.

#### Menu-structure:

Menu-structure:		
File		
	New	
	Open	
	Save	
	Save As	
	Printer configuration	
	Exit	
View		
	Toolbar	
	Status line	
Module		
	Select	
	Read	
	Write	
	Blanktest	
	Compare	
	Block list	
	Erase	
Configuration		
-	Interface	
	Language	
	Word/Block	
	SYSID	
	Display checksum	
Window		
	Overlapped	
	Side-by-side	
	Top-on-top	
	Group symbols	

Help

Contents Usage of help Introduction Version-history About WinPrommer

#### Block

All None Exchange

#### **File-formats:**

- \*.\* All Files. It is tried to choose a file-format according the extention. If no appropriate file-format is found, the binary format is used
- \*.BIN Binary File \*.S5D Step-5 File \*.S7P Step-7 File (structure) ET-100 File \*.308 \*ET.200 ET-200 File \*.2BF ET2-Binary Export \*.HEX Intel-Hex-Format \*.EPR Motorola-Hex-Format \*.525 CP-525/524 Files Q\*.\* CP-5431 File A\*.\* CP-1430/CP-143 File

#### **Technical data:**

Size (S x H x D):	130 x 45 x 80 mm
Case-Type:	metal casing, powder-coated

For more Information of the Mini-Prommer-III or to get the actual Manual or the actual operating software WinPrommer, you find the information under

Under the web-address https://www.process-informatik.de are product specific documentations or software-driver/-tools available to download. If you have questions or suggestions about the product, please don't hesitate to contact us.

Process-Informatik Entwicklungsgesellschaft mbH Im Gewerbegebiet 1 DE-73116 Wäschenbeuren +49 (0) 7172-92666-0

> info@process-informatik.de https://www.process-informatik.de

Copyright by PI 2006 - 2024

### Menutree Website:

- + Products / docu / downloads
  - + Hardware
    - + Memory modules / Prommer + MINI-PROMMER-III







Please make sure to update your drivers before using our products.



Communication with S7-PLC via USB, just how and with what?

Data-communication with S7-PLC from PC or other devices via USB, which interface is required. Questions you don't have to worry about. With "S7 over USB" you get the right interface-products for PPI, MPI and Profibus.

Which one you use then is up to you.