Step5/7-Programming system
PG-2000

Installation note:

Load your license file using the link given in your personal license email.
The password for extraction can also be found in this email. Then copy this
file into the folder of the installed PG-2000 software (demo version).
After restarting the software, your license is active.

Under the web-address https://www.process-informatik.de are product specific
documentations or software-driver/-tools available to download.
If you have questions or suggestions about the product, please don't hesitate to contact us.

Process-Informatik Entwicklungsgesellschaft mbH
Im Gewerbegebiet 1
DE-73116 Wäschenbeuren
+49 (0) 7172-92666-0

info@process-informatik.de
https://www.process-informatik.de

Menutree Website:

+ Products / docu / downloads
  + PG2000 teleservice option

QR-Code Website:

Please make sure to update your drivers before using our products.

PG-interface of the S5-PLC occupies with a panel and program changes in the controller should be performed? No desire/leisure/possibility to plug permanently between panel and programming-device?

Connect the device from the PG-switch-series to the S5-PLC as well as panel and programming-device, and you decide who from the two participants (PANEL or PG) with the control communicates. Whether with toggle-switch (PG-SWITCH) or with 24V DC (PG-SWITCH-II) or permanently connected by preceding [PANEL and PLC permanently connected, communication is running; As soon as PG is plugged into PG is also switched; disconnect PG and panel has access] (PG-SWITCH-III), switching to your requirements and no permanent change.

Message dispatch from the PLC

Send directly from your PLC news, statuses, alarms as SMS or email.

Connect each S7-TCP-IP panel to your S5.
Now also available via WLAN for mobile workstations.
PARALLEL several panels and even simultaneous PG connections possible.
Include hard-to-reach places in your ERP system.

Direct-mode "extended serial interface"

There is an unsupported control or data logger or converter integrated in your installation which protocol is not supported? No problem, the signs that the PC in the office sends will be transferred via telephone line by the Direct-mode, and on-site reproduced by the TP-II. The way back is identical. So in that case there's also a communication to the electronic devices available.

You need ALF to connect to a reachable WLAN, but only have a patch-cable? No problem, ALF provides "autonegotiation" and this means that he recognises a connected cable (patch-cable or cross-over-cable) and surround the pinning according to the cable, so a communication is possible.

Detection and logging of unauthorized access in the defined Profinet
 Attempted break-ins and access to the network are recognized immediately and e.g. reported by email
 Logging of all accesses in the network for historical processing
 Possible data-storage USB-stick or FTP-server via USB-network-stick.