Step5/7-Programming system
PG-2000

Installation note:

Load your license file using the link given in your personal license email.
The password for extraction can also be found in this email. Then copy this
file into the folder of the installed PG-2000 software (demo version).
After restarting the software, your license is active.

Under the web-address https://www.process-informatik.de are product specific
documentations or software-driver/-tools available to download.
If you have questions or suggestions about the product, please don't hesitate to contact us.

Process-Informatik Entwicklungsgesellschaft mbH
Im Gewerbegebiet 1
DE-73116 Wäschenbeuren
+49 (0) 7172-92666-0

info@process-informatik.de
https://www.process-informatik.de

Menutree Website:

+ Products / docu / downloads
  + PG-2000 STEP5-STL

QR-Code Website:

Please make sure to update your drivers before using our products.

Via digital input triggered DB-backup/-restore without additional PC via MPI/Profibus to FTP-server

Remote-maintenance of a Siemens-S5-controller with S5-LAN++ on PD-port via secure VPN-tunnel and scalable firewall

Move wirelessly around the Mitsubishi-PLC and communicate for example ONLINE in the status

Protection for data-dump and modification

You want to protect your system against unauthorized access and changes? No problem, with the S7-firewall you secure your system against unauthorized access and thus prevent deduction or alteration of your system and process data.

Do you have a PLC without CP343-1 or CP443-1 and a TP-II as remote maintenance device? Then activate the CP-mode of the TP-II and your visualisation goes directly ONLINE via the LAN of the TP-II.

Data backup S5-PLC on FTP-server via dig. IO

Via digital input triggered DB-backup/-restore without additional PC via PG-socket and Ethernet to FTP-server