

Step5/7-Programming system PG-2000

Installation note:

Load your license file using the link given in your personal license email. The password for extraction can also be found in this email. Then copy this file into the folder of the installed PG-2000 software (demo version). After restarting the software, your license is active.

Under the web-address <https://www.process-informatik.de> are product specific documentations or software-driver/-tools available to download.

If you have questions or suggestions about the product, please don't hesitate to contact us.

Process-Informatik Entwicklungsgesellschaft mbH
Im Gewerbegebiet 1
DE-73116 Wäschenbeuren
+49 (0) 7172-92666-0
info@process-informatik.de
<https://www.process-informatik.de>

Menutree Website:

- + Products / docu / downloads
- + Software
 - + Programming-software PG-2000 Step5 & Step7
 - + STEP 7 (Freeware)

QR-Code Website:




```

000 Name          Typ
001 001 SU_CLASS   byte
002 001 SCN        byte
003 001 PRIORITY   byte
004 001 OB_NUMBR   byte
005 001 RESERVED_1 byte
006 001 RESU_CYCLE int
007 001 HIR_CYCLE  int
008 001 LAR_CYCLE  int
009 001 DATE_TIME Date_and_Time
Network 1 von 3      1
+-----+
|S2|
|SPN|
|Hir|
|Lar|
|Date|
+-----+
weil INOP 0

```

Please make sure to update your drivers before using our products.

Watching of S7-PLC-devices via LAN without Ethernet-CP



Your panel only has a LAN-socket as PLC-interface? No problem, connect this socket with the S7-LAN or the MPI-LAN-cable and plug it directly on the PPI/MPI/Profibus of the PLC. Then access to the variables and data of the PLC is already available.

Detect Profinet burglary




Detection and logging of unauthorized access in the defined Profinet

Attempted break-ins and access to the network are recognized immediately and e.g. reported by email

Logging of all accesses in the network for historical processing


Possible data-storage USB-stick or FTP-server via USB-network-stick.

Data backup S7-PLC over MPI/Profibus on SD-card




S7-PLC triggered DB-backup/-restore without additional PC via MPI/Profibus on SD-card

Data backup S5-PLC on FTP-server via dig. IO



Via digital input triggered DB-backup/-restore without additional PC via PG-socket and Ethernet to FTP-server

Wireless around the S5-PLC



Move wirelessly around the S5-PLC and communicate for example ONLINE in the status

Wireless around the Mitsubishi-PLC



Move wirelessly around the Mitsubishi-PLC and communicate for example ONLINE in the status