

Short instruction/handling Ethernet over USB



The "Ethernet over USB"-adapter serves as an extension with an additional Ethernet-port.

It can be used for these devices :

- TINA
- TINA-II
- ProfiNet - WATCHDOG
- CONNECT (not for LTE-version)
- CONNECT-II

The adapter is plugged into the USB type A socket of the device. As soon as the adapter has been recognized by the device and a LAN cable is connected, the two integrated LEDs start to light up:

Green Link-status

Yellow Data communication (flashes depending on data)

You can now access by the device-specific default IP-address 192.168.0.1.

Under the web-address <https://www.process-informatik.de> are product specific documentations or software-driver/-tools available to download.
If you have questions or suggestions about the product, please don't hesitate to contact us.

Process-Informatik Entwicklungsgesellschaft mbH

Im Gewerbegebiet 1

DE-73116 Wäschenbeuren

+49 (0) 7172-92666-0

info@process-informatik.de

<https://www.process-informatik.de>

Copyright by PI 2019 - 2026

Menutree Website:

+ Products / docu / downloads

+ Ethernet over USB




QR-Code Website:




Please make sure to update your drivers before using our products.

Data backup S5-PLC on SD-card



S5-PLC triggered DB-backup/-restore without additional PC via PG-socket and Ethernet on SD-card

Communication with Win98 – XP/Vista/7/8/10/11 via USB to S5-PLC




You still have a PC with Win98 and Step5-package and would like to go Online on your S5-PLC via USB? No problem, the provided virtual Com-Port PLCVCom emulates a COM-port on your PC with which you go Online. With a patchtool for the Siemens Step5-software, which is provided as well, nothing else stands in your way to communicate via LAN.

Programming of S5-PLC's via LAN



You would like to respond to your S5-PLC via LAN, but not integrate an Ethernet-CP?
No problem, plug the S5-LAN++ on the PD-interface and access via LAN.

Operation as bridge



You have two or more clients which should communicate together without LAN-cable-connection? No problem, you connect a "Access-Point" configured ALF to this device and to the other device a "Client" configured ALF. Then connect the "Client" with the "Access-Point" and the device are able to communicate together.