Fiber optic adapter for differential transmission (K) user manual

(english)



Art.Nr. 9531-K

11.02.2021

© PI 2021

index of contents

Fiber optic adapter for differential transmission (K)

0.1 LWL ADAPTER

- 0.1.1 General to beam-waveguide
- 0.1.2 General to LWL-ADAPTER
- 0.1.3 Hardware connection on iBx-clamp
- 0.1.4 Hardware connection between two LWL-Adapter
- 0.1.5 Hook-up-example
- 0.1.6 Technical data LWL Adapter

Fiber optic adapter for differential transmission (K)


0.1 LWL ADAPTER


0.1.1 General to beam-waveguide

To the basic advantages to the LWL-technique opposite wiring with copper conductor belongs among other things:

• Interference protection	 * beam-waveguides are insensitive also without shielding opposite electromagnetic fields * No "antenna effect" of the conductor
 potential separation 	 * beam-waveguides are insulators (ca.110kV/m). * No current compensations due to various earth-potentials.
 Lightning protecton 	* beam-waveguides are insulators
 Ex-protection 	* No spark genesis at separation or cable disruption.
 Bugging protection 	* No crosstalk.
• Weight	* Low cable mesures.

fiber (without coat) has a core and an outside skin which one another refraktionindex for the light. Around the fiber is because of one possible inductive disturbance a PVC or PE coat which protects the fiber from external interferences.





	glass fiber	synthetic material fiber
dk = diameter core	62,5µm	980µm
dm = diameter outsideskin	125µm	1000µm

0.1.2 General to LWL-ADAPTER

There are two different models for the general application:

- LWL-Adapter für Kunststoffaser-Leitungen (LWL-Adapter for synthetic material fiber lines)
- LWL-Adapter für Glasfaser-Leitungen
- (LWL-Adapter for glass fiber lines)

The complete electronics are integrated in an industrial metal casing (which is prepared for the mounting of a switchgear cubicle or a switchboard). The device can be fastened directly to the switchboard.

Connection, mechanics, pin seizure and electrical data meet the respective iBx specification.

However, the LWL-System can individually be used by other userspecific hook-ups (RS485 4-wire interface).

0.1.3 Hardware connection on iBx-clamp

The entrance and exit represent a RS485 interface on the wired side of the LWL-Adapter. One of these interfaces of usual connection is needed therefore:

To use is a cable of the type $2 \times 2 \times 0.25$ mm2 in pairs with shield. This cable is attached by screwterminals at the LWL-Adapter.

0.1.4 Hardware connection between two LWL-Adapter

One in this case distinguishes between LWL-Adapter for **synthetic material fiber** and LWL-Adapter für **glass fiber**:

Important at both systems:

Should the cable get canned at own is open good polished fraying respect

• LWL-Adapter for synthetic material fiber:

Cable type:	Duplex Typ POF (980µm/1000µm) coat PE or PVC
Plug type:	DST-MV (Duplex-plug with locking system) [HP-Typ HFBR4516] DST-OV (Duplex-plugr without locking system) [HP-Typ HFBR4506] Two cable fibers are summarized in a plug respectively
Länge:	ca.145m
Wellenlänge:	665nm

LWL-Adapter for glass fiber:

- Cable type: only duplex Typ 6F 62,5 ($62,5\mu$ m/125 μ m) coat PE or PVC (please do not use cable type GF 50, because the transmitter and receiver are designed for a fiber cross-section of 62.5 μ m/125 μ m. A cross section of 50 μ m/100 μ m would bringing heavy loss of quality with it.)
- Plug type: F-SMA terminal with screwconnectors for every cable fiber one connector

Length: ca. 2,5km

Wavelength:: 820nm

0.1.5 Hook-up-example



0.1.6 Technical data LWL Adapter

power supply:	24V/DC +/- 20%
power draw:	1,5 power power VA
interfaces:	2 x screw terminals for the voltage connection 4 x screw terminal for differential transmission (TX & RX) 2 x socket, for F-SMA LWL connector
max. Length between two adapters:	glass fiber = ca. 2,5 km thetic material fiber = ca.145 m
working temperature:	5 to 55 Grad Celsius
case:	powder coated metal case with mounting flange
dimensions:	75 x 65 x 30 mm